

AMFB8760, AMFB8770, ACMFB8760, & ACMFB8770

Installation of CARBONETIC Front LSD for Lancer Evo (with viscous center)

- 1 Lathe the viscous coupling and cut the darkened area A (enlarged diagram is on the page 3)
- 2 Remove the two spacers
- 3 Replace the stock front differential with CARBONETIC LSD
- 4 Assemble the output flange, the viscous coupling, and the final gear. Make sure that the center of the output flange and the viscous coupling do not deviate more than 0.1 mm.

* parts with this mark are included in the LSD kit





